




4003

EASY SHARP DIAMOND



- Ergonomic side edge sharpener
- Pocket size, «on the slope» use also
- Easy handling, steady grip, maximum accuracy
- Best results, minimum effort
- Right and left hand use
- For ski and snowboard
- Best if use with water or a polishing solution
- Spare diamond **5160**




4004

EASY SHARP KIT

- Ergonomic side edge sharpener
- Pocket size, «on the slope» use also
- Easy handling, steady grip, maximum accuracy
- Best results, minimum effort
- Right and left hand use
- For ski and snowboard



STEP 1 | **ZIRCONIUM:**
to remove rock damaged spots and burrs before using the file.
(Spare part **5140**)



STEP 2 | **FILE:**
to sharp and set up the side edge angle.
(Spare part **5105**)



STEP 3 | **DIAMOND:**
to polish and super finish the ski and snowboard edges.
Best if used with water or with a polishing solution.
(Spare part **5160**)